

# Quikpop Glass Popcorn Maker Instructions

---

For a single serving (approx. half a pot) of popcorn fill the silicone lid with kernels to the 1oz serving line. For a larger serving, fill to 2oz line.

Pour kernels into the bottom of the glass popper.

Place unmelted, salted butter in the silicone lid and place lid on top of glass popper. When heated the butter will melt onto popped kernels.

Heat popper in the microwave for approx. 2 minutes (popping times may vary). Continue popping until pops are a few seconds apart. Do not leave microwave unattended while popping.

Remove Quikpop popper from microwave and pour popped corn into a bowl. Add salt or flavouring to taste.

## **CAUTION:**

- Glass handle should stay relatively cool while heating but it is recommended to always use an oven mitt when removing freshly popped popcorn.
- Silicone lid will get hot and may have hot butter residue. Always use an oven mitt to remove lid to prevent burns.
- Let the Quikpop popper cool before washing. Never rinse hot glass with cold water.
- Quikpop popper and lid are dishwasher safe.
- Never microwave empty popper
- Adult supervision is required when using the Quikpop popper. Not for use by children.
- Do not use Quikpop popper on stovetop. Microwave only.