






Audrey Dining Chair

Assembly Instructions

STK #82889, #82891



Assembly Tips



Count

all pieces and hardware before assembling.

Review

the instructions from beginning to end before getting started.




Make Space

Keep plenty of clear space and use a clean rug or drop cloth if needed.






Double Check

that all pieces are in place before tightening screws. This ensures quick assembly.

Parts List


Parts ID	Image	Description	Qty
A		Chair Back	1
B		Seat Cushion	1
C		Front Legs	2

Hardware Parts

Parts ID	Image	Description	Qty
1		M8x60mm	4
2		M8x50mm	5
3		Washer	9
4		Spring Washer	9
5		Allen key	1

Assembly Instructions


1



Assemble the cushion seat (B) to chair back(A) using bolt #2, Spring washer #4 and flat washer #3.


DO NOT TIGHTEN THE BOLTS ON THIS STEP

2



Put the front leg (C) into the seat part (B).


3



Assemble front legs (C) to cushion seat (B) using Bolt #1, spring washer #4 & flat washer #3.


DO NOT TIGHTEN THE BOLTS ON THIS STEP

4



Turn over the chair and sit on it to make sure 4 legs are in the same level

5



Now tighten all the bolts and cover the bottom seat cover

6

