


# Audrey Dining Chair





## Assembly Instructions

STK #82889, #82891



### Assembly Tips

\* Two adults required to assemble the product



#### Count

all pieces and hardware  
before assembling.

#### Review

the instructions from  
beginning to end before  
getting started.




#### Make Space

Keep plenty of clear  
space and use a clean rug  
or drop cloth if needed.






#### Double Check

that all pieces are in place before  
tightening screws. This ensures  
quick assembly.

## Parts List


Parts ID	Image	Description	Qty
A		Chair Back	1
B		Seat Cushion	1
C		Front Legs	2

## Hardware Parts

Parts ID	Image	Description	Qty
1		M8x60mm	4
2		M8x50mm	5
3		Washer	9
4		Spring Washer	9
5		Allen key	1

## Assembly Instructions


1



Assemble the cushion seat ( B ) to chair back( A ) using bolt #2, Spring washer #4 and flat washer #3.


**DO NOT TIGHTEN THE BOLTS ON THIS STEP**

2



Put the front leg ( C ) into the seat part ( B ).


3



Assemble front legs ( C ) to cushion seat ( B ) using Bolt #1, spring washer #4 & flat washer #3.


**DO NOT TIGHTEN THE BOLTS ON THIS STEP**

4



Turn over the chair and sit on it to make sure 4 legs are in the same level

5



Now tighten all the bolts and cover the bottom seat cover

6

