


Cole Bonded Dining Chair






Assembly Instructions

STK #82892



Assembly Tips

* Two adults required to assemble the product



Count

all pieces and hardware
before assembling.

Review

the instructions from
beginning to end before
getting started.




Make Space

Keep plenty of clear
space and use a clean rug
or drop cloth if needed.






Double Check


that all pieces are in place before
tightening screws. This ensures
quick assembly.

Parts List

Parts ID	Image	Description	Qty
A		Chair Back	1
B		Seat Cushion	1
C		Front Legs	2


Hardware Parts

Parts ID	Image	Description	Qty
1		M8x60mm	4
2		M8x50mm	5
3		Washer	9
4		Spring Washer	9
5		Allen key	1


1


Assemble the cushion seat (B) to chair back (A) using bolt #2, spring washer #4 and flat washer #3.

DO NOT TIGHTEN THE BOLTS ON THIS STEP


2


Put the front leg (C) into the seat part (B).


3


Assemble front legs (C) to cushion seat (B) using Bolt #1, spring washer #4 & flat washer #3.

DON'T TIGHTEN THE BOLTS ON THIS STEP

4


Turn over the chair and sit on it to make sure 4 legs are in the same level

5


Tighten all the bolts and cover the bottom seat

6
