





Caban Outdoor Couch & Dining Table

Assembly Instructions

STK #92631 / 7702



Assembly Tips



Count

all pieces and hardware before assembling.

Review

the instructions from beginning to end before getting started.

Make Space

Keep plenty of clear space and use a clean rug or drop cloth if needed.

Double Check


that all pieces are in place before tightening screws. This ensures quick assembly. .

Caban Outdoor Couch & Dining Table


Assembly Instructions

STK #92631 / 7702


TIP: Avoid using sharp objects such as a knife to open the packaging as you may accidentally damage the furniture



A.1x




B.1x




C.1x




D.1x




E.1x




F.1x




G.1x



H.1x



I.1x



J.1x



K.2x



L.1x



M.13x
M6X40mm




N.15x
M6X35mm



O.4x
M6X30mm




P.8x
M6X20mm



Q.1x



T.2x



U.1x





V.1x

Caban Outdoor Couch & Dining Table

Assembly Instructions

STK #92631 / 7702

Bench




Caban Outdoor Couch & Dining Table

Assembly Instructions

STK #92631 / 7702

TIP: Don't fully tighten bolts until assembly is complete.

3 Seat Corner Sofa




Caban Outdoor Couch & Dining Table


Assembly Instructions

STK #92631 / 7702

Dining Table



1



2

Caban Outdoor Couch & Dining Table

Assembly Instructions

STK #92631 / 7702

3 Seat Corner Sofa

