

Instructions

STK #98619, #1359






USE INSTRUCTIONS



1

Put your feet on the lower cross bar and, exerting mild force, push outwards at cross bar (A). At the same time, push the seat backward with mild force at (B).



2

Flip part (C) upwards at both handles to have recliner stay in desired angle.